

ASSEMBLY INSTRUCTIONS

MODEL: PPPxxxxSICLR+ PPPxxxxSICHARCLR



Before assembly, please remove all parts from carton, verifying that you have the correct quantities, and read all the instructions.

Included:	Included:	Sold Separately:
<p>"A" self drilling screw #10x5/8" qty = 8 pcs</p>	<p>"B" M6x16 bolt qty = 6 pcs</p>	<p>Leg bracket (PPPDELFOOTCPR) V base castor Leg qty = 2 pcs</p>

<ol style="list-style-type: none"> Place panel down on a clean flat surface for assembly. Panel comes with end cap installed. Remove end caps temporarily. 		
--	--	--

<ol style="list-style-type: none"> Place the leg mounting against the bottom corner of the panels, so the mounting holes on the leg bracket line up with the pre-drilled holes on the bottom of the panel. Using bolt "B" insert, three bolts into the pre-drilled holes through the bottom bracket. Using screw "A" insert the screws through the side bracket holes directly into the panel. (Note: There aren't pre-drilled holes on the side of the panel, for this step.) 		
---	--	--

<p>Post side</p>	<p>Panel base side</p>		
<ol style="list-style-type: none"> Install the remaining screw "A" into the bottom of the leg bracket. Repeat these steps on the opposite side of the panel. Once completed, replace end caps. 			

⚠ ATTENTION ⚠

Ensure all bolts and screws are tightened, check bolts and screws every 6 months.

If any parts are missing, broken, damaged or worn, stop use of product until repairs have been made using factory authorized parts.

Failure to follow these warnings may result in injury.