

ASSEMBLY INSTRUCTIONS


Remove all items from the carton . Verify all pieces before assembly.


PARTS LIST


KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION
1	5	Caster	7	1	Backrest Post	14	2	Arm Width Adjustment
2	1	Base	8	1	Backrest Screw			Knob + Washers
3	1	Seat Post	9	1	Seat	15	1	Back Post Bellow
4	1	Seat Post Cover	10	1	Mechanism	16	2	Back Post Bellow Screw
5	1	Footring + Height Adj.	11	4	Mechanism Screw	17	3	Mechanism Bracket
		Knob	12	2	Armrest Bracket			Screw + Washer
6	1	Backrest	13	2	Armrest	18	1	Allen Wrench














(A) SEAT HEIGHT ADJUSTMENT: Pull lever up and downward. Release lever when desired position is reached.

PREVENTIVE MAINTENANCE AND WARNING!

- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME. DO NOT USE THIS CHAIR AS A STEP STOOL / LADDER. DO NOT SIT ON ANY PART OF THE CHAIR EXCEPT THE SEAT. DO NOT USE CHAIR ON UNEVEN FLOOR SURFACES. DO NOT USE CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE TICKLITENED.
- ARE TIGHTENED.
 EVERY SIX MONTHS, PLEASE MAKE SURE ALL BOLTS, SCREWS AND KNOBS ARE FULLY TIGHTENED TO ENSURE STABILITY.
- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OF THE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS.
 DISPOSE OF PACKAGING PROPERLY. PLASTIC BAG IS NOT A TOY. DO NOT USE PLASTIC BAG AS HEAD COVERING IT MAY CAUSE SUFFOCATION.
 FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.
- NOTE: SOME SCREWS MAY BE PREASSEMBLED. IF PREASSEMBLED, IGNORE ASSEMBLY INSTRUCTIONS.