



PL Laminate
Standard Key Set



PL Laminate
Master



PL Laminate
Core Removal



Metal Storage
Standard Key Set



Metal Storage
Master Key



Metal Storage
Core Change Key

PL Cabinets

Cabinet locks are used with laminate DOORS.

PLMKEY

PL MASTER KEY

PLMKEY is the laminate master key, used to unlock any cabinet.

Also used for pedestals



PLLOCKCORE

PL LOCK CORE KIT

PLLOCKCORE replaces your existing lock core. Includes new core, core removal key and 2 new keys. To remove core, cabinet must be unlocked. Also used for pedestals



PLLOCKS CABINET PLLOCKS-SILV CABINET

PL CABINET LOCK ASSEMBLY

Complete lock assembly. Replaces your existing cabinet lock assembly.



Silver for use with WHITE laminate products.

PL Pedestals

Pedestal locks are used with laminate DRAWERS.

PLMKEY

PL MASTER KEY

PLMKEY is the laminate master key, used to unlock any pedestal.

Also used for cabinets



PLLOCKCORE

PL LOCK CORE KIT

PLLOCKCORE replaces your existing lock core. Includes new core, core removal key, and 2 new keys. To remove core, pedestal must be locked. Also used for cabinets



PLLOCKS PEDESTAL PLLOCKS-SILV PEDESTAL

PL PEDESTAL LOCK ASSEMBLY

Complete lock assembly. Replaces your existing pedestal lock assembly.



Silver for use with WHITE laminate products.

Metal File Drawers

8000 keys and cores used with all metal files.

8000MASTERKEY

METAL STORAGE MASTER KEY

8000MASTERKEY is the metal file master key, used to unlock any metal file.



8000CORREVKEY

Core Change Key

8000CORREVKEY is the metal file change key, used to remove the lock core on metal files.



8000LOCKCOREKIT

LOCK CORE KIT

8000LOCKCOREKIT replaces existing lock core. Includes new core and 2 new keys.

To remove core, file must be locked.

Requires core change key, 8000CORREVKEY




Locking Products

All lockable products PCFG sells come with locks and 2 keys. Different products will not automatically be keyed alike, but if an item has multiple locks the locks on that item will be keyed alike- for example the PL207 wardrobe ships with a cabinet and pedestal lock, keyed alike.

Laminate Locks

There are two types of laminate locks:
locks for a pedestal (drawers) and locks for cabinet (doors).



Metal Storage Locks

All metal files use the same style lock.
To remove lock core you must order 8000CORREVKEY



How to Order

Are you ordering more than 1 item?

- ↳ **NO** - your product will arrive with a lock and set of keys, no need to order additional locks.
- ↳ **YES** - do you need your items to be keyed alike?
 - ↳ **NO** - your products will arrive keyed separately, no need to order additional locks.
 - ↳ **YES** - you will need to order additional locks in order to key alike.

How to Key Alike

PL Laminate: Determine how many lock cores you need. You will be ordering lock core kits.

PO should read: PLLOCKCORE (x qty needed), "KEY ALIKE"

Metal Storage: Determine how many lock cores you need. 8000CORREVKEY required to remove core and key alike.

PO should read: 8000CORREVKEY qty 1, 8000LOCKCOREKIT (x qty needed), "KEY ALIKE"

Frequently Asked Questions

Can I order a replacement key for lock core number X?

PCFG does not sell individual replacement keys. The best solution is to purchase a new lock core or complete lock.

I have lost my key! I am locked out, help!

The best option is to order a Master Key and replacement lock core. This will allow you to open the lock out and replace with a new secure lock core and set.

My pedestal is locked and I must urgently open, emergency help!

If you must open your drawer and do not have a master key you can drill out the core. You can then replace the damaged lock with a complete lock kit assembly or lock core.

I have a lock core change key but can not unlock my drawer?

8000CORREVKEY and PL core removal key will not unlock your item. To open you will need the original key or a master key.

PL cabinet lock cores can be removed when the door is locked, but this will not allow you to open the door, you will still need a master key.