


ASSEMBLY MANUAL


Packing list


Frame	pcs
Pre-assembled frame set	
Outer pipe	2
Connection pipe	2
Control box	1
Gear motor	1
Aluminum extension set	1
Cable clamp	7
Set screw for con. pipe, M8 x 35 mm	8
Column	2
End pipe	2
Foot	2
Rubber washer	18
Accessory	pcs
Control	1
AC cable	1
AC cable Hardware	1 pcs
Hardware	pcs
Hardware Screw for column, M6 x 16 mm	pcs
Hardware Screw for column, M6 x 16 mm Screw for foot, M10 x 16 mm	pcs 8
Hardware Screw for column, M6 x 16 mm Screw for foot, M10 x 16 mm Screw for control, Ø4 x 25 mm	pcs 8 8 2
Hardware Screw for column, M6 x 16 mm Screw for foot, M10 x 16 mm Screw for control, Ø4 x 25 mm Allen key for foot, 5 mm	pcs 8 8 2
Hardware Screw for column, M6 x 16 mm Screw for foot, M10 x 16 mm Screw for control, Ø4 x 25 mm Allen key for foot, 5 mm Allen key for column, 4 mm	pcs 8 8 2 1


Reset the desk before use


Press both buttons at the same time for 3 seconds. Continue pressing the buttons until both columns are in lowest position. When finish reset, the control box makes a sound and the buttons can be released. Now the system is operational.















ASSEMBLY MANUAL

